

Shift Boot Removal & Installation

Liability Waiver Document

Do it yourself articles:

All information contained herein should be independently verified and confirmed. Coby Wheel (Michael LeMon) does not accept any liability for any injury, loss or damage whatsoever caused in reliance upon such information.

Reader agrees to indemnify and hold harmless Coby Wheel (Michael LeMon) from and against any damages, cost and expenses, including any legal fees, potentially resulting from the application or use of any of our DIY information provided. This disclaimer applies to any damages or injury caused by any error, omission, or under any other cause of action.

Reader agrees to assume all risk resulting from the application of any of the information provided by Coby Wheel (Michael LeMon).

By using this web site, including any applets, software and content contained therein, the visitor agrees that the use of this web site and its information is entirely at his/her own risk.

BMW E46 Shift Boot Removal and Installation Guide

BMW boots are glued to a plastic frame which then boot is just clipped into the cars console.

1. Remove shifter knob give it a good pull straight upward to remove (if you have an aftermarket knob you may want to check and make sure it does not have a set screw)



Image 1

2. Carefully remove shift boot by squeezing the left and right sides inwards and pulling up.



Image 1



Image 2

3. Now that the shift boot and its mounting clip are out, carefully remove the leather boot from the frame keeping note of where the seams of the original boot are located onto the boot clip. Clean the frame of glue if needed and glue your new boot onto the mounting clip using good epoxy glue or a good fabric glue like Fabri-Tac which can be found at any Wal-Mart or fabric shop.



Image 1

4. Then reinstall the boot and frame assembly.



Image 1

Enjoy and Thank You!